

INSTA ARCH CORPORATION

“The Original Arch”

Split Unit Installation Instructions for Standard or Elliptical Insta Arches 16” through 96”



Begin by sheetrocking the square perimeter of the entranceway.



Insert Insta Arch secure to top. Use straight edge of the unit to level off and square.



Hold secure and nail perimeter of Insta Arch every three-four inches on both sides.



Insert other half of unit to create the Insta Arch. Repeat step two and three as shown above.



Align corner bead in the middle and nail on both sides to adjoin Insta Arch. Also, adjoin corner bead to the four bottom corners and set into place.



Evenly cement Insta Arch, feather edges, and tape in smooth on both sides and underneath.



“A Perfect Arch in Fifteen Minutes”

INSTA ARCH®

PUT YOUR IMAGINATION TO WORK

For further information please contact: Insta Arch Corporation
17 Hamden Park Drive, Hamden, CT 06517 – 203.288 ARCH
203.288.3836 Fax www.InstaArch.com U.S. Patent #4400917

Tool & Material List:

Drywall, Hammer, and Nails.
Tape Measure, Level, and Cornerbead.
12” Trowel or Blade and 6” Taping Knife.
Mud pan or Hawk, Cement and Sand Paper.